

(GB) Mounting instructions: Side bar series GM/GC/BM/BC/RM/RC

Volkswagen Caddy / Caddy Maxi



SW13 (23Nm)



30 Min.

Version: 1.07 April 2013



GB

Assembly sequence:

- Step 1: Get the side bars out of their packaging and lay them lengthwise beside the car at their position.
- Step 2: Look at the side bar mounting lips and then check the cars sills which rubber seals need to be removed, see figure 2.
- Step 3: Place the M10 plates in the sills slotted hole, see figure 3.
- Step 4: Use the M10x40 bolts together with the rings in order to draw the sidebar against the car, see figure 4. Partly tighten them.
- Step 5: Position the side bar as you want it to be and now completely tighten the bolts.

